

BRUCE'S CUSTOM COVERS

989 E. California Ave. Sunnyvale, CA 94085 www.aircraftcovers.com

a div. of Canvas Works. Inc.

Phone: 408/738-3959 Toll Free (U.S.): 800/777-6405

Fax: 408/738-2729 E-mail: bruce@aircraftcovers.com


manufacturer of the finest custom-made aircraft covers

CANOPY COVER ORDERING INFORMATION, Page 1

INSTRUCTIONS: Print Form, Fill Out, Fax to 408/738-2729 NAME_ SHIPPING ADDRESS PHONE, FAX, EMAIL ___ MasterCard [PAYMENT BY: Visa Amex Discover All shipments are F.O.B. Sunnyvale, California, shipping by UPS (Ground or 2nd Day Service) unless requested otherwise. _____ Exp. Date ______ V-Code __ Credit Card Number _ * Visa, Mastercard, Discover: last 3 numbers on back of card, right of signature. Amex: 4 smaller numbers printed on face of card. AIRCRAFT COLORS (be specific) ___ (check one) DO YOU WANT YOUR N-NUMBER IMPRINTED ONTO COVER? (\$30 CHARGE) Specify below ALL of the items you would like to order. See Technical Sheet For Part Numbers (or fill in description) quant | description part number price TEMPERATURE PROBE (OAT) WORKSHEET Not on this aircraft Co-Pilot Side Pilot Side OAT on Windshield Distance from top Windshield Offset from OAT on Side Window Centerline Distance back OAT Offset from fwd edge (check one) Distance up from lower edge OAT Height OAT Height Additional Ordering Information: see Page 2

rev. date: 2/15/07

NAME: ANTENNA PLACEMENT WORKSHEET INSTRUCTIONS: Print Form, Fill Out, Fax to 408/738-2729





BRUCE'S CUSTOM COVERS

989 E. California Ave. Sunnyvale, CA 94085 www.aircraftcovers.com Phone: 408/738-3959 Toll Free (U.S.): 800/777-6405

Fax: 408/738-2729

E-mail: bruce@aircraftcovers.com

a div. of Canvas Works, Inc.

manufacturer of the finest custom-made aircraft covers

Measuring for a Propellor Cover

INSTRUCTIONS: Print Form, Fill Out, Fax to 408/738-2729

Spinner and blade dimensions on propellors vary, even among similar models.

Producing a well-made propellor cover depends upon the following measurements.

If you have any questions or problems, please call.

Please Check One:

2-Blade

3-Blade

4-Blade

A _____ (measure along surface of cone)

B _____ (measure "straight line" base to tip)

C _____ (base to top of blade root opening)

D _____ (provide diameter or circumference)


E _____ (provide diameter or circumference)


F _____ (blade root to prop tip)

G _____ (trailing edge to leading edge)

H _____ (trailing edge to leading edge)

J _____ (trailing edge to leading edge)





VENTURI

Phone: 408/738-3959 Toll Free (U.S.): 800/777-6405

Fax: 408/738-2729


E-mail: bruce@aircraftcovers.com

manufacturer of the finest custom-made aircraft covers

a div. of Canvas Works, Inc.

TUBE PLACEMENT WORKSHEET

INSTRUCTIONS: Print Form, Fill Out, Fax to 408/738-2729



rev. date: 2/15/07