



**BRUCE'S CUSTOM COVERS**  
 989 E. California Ave.  
 Sunnyvale, CA 94085  
 www.aircraftcovers.com  
 a div. of Canvas Works, Inc.

Phone: 408/738-3959  
 Toll Free (U.S.): 800/777-6405  
 Fax: 408/738-2729  
 E-mail: bruce@aircraftcovers.com  
 manufacturer of the finest custom-made aircraft covers

# CANOPY COVER ORDERING INFORMATION, Page 1

INSTRUCTIONS: Print Form, Fill Out, Fax to 408/738-2729

NAME \_\_\_\_\_

SHIPPING ADDRESS \_\_\_\_\_

PHONE, FAX, EMAIL \_\_\_\_\_

PAYMENT BY: Visa  MasterCard  Amex  Discover  (check one)

All shipments are F.O.B. Sunnyvale, California, shipping by UPS (Ground or 2nd Day Service) unless requested otherwise.

Credit Card Number \_\_\_\_\_ Exp. Date \_\_\_\_\_ V-Code \_\_\_\_\_

\* Visa, Mastercard, Discover: last 3 numbers on back of card, right of signature. Amex: 4 smaller numbers printed on face of card.

AIRCRAFT TYPE \_\_\_\_\_ YEAR \_\_\_\_\_ N \_\_\_\_\_  
reg. number

AIRCRAFT COLORS (be specific) \_\_\_\_\_

DO YOU WANT YOUR N-NUMBER IMPRINTED ONTO COVER? (\$30 CHARGE) YES  NO  (check one)

**Specify below ALL of the items you would like to order.  
 See Technical Sheet For Part Numbers (or fill in description)**

part number	quant	description	price

## TEMPERATURE PROBE (OAT) WORKSHEET

Not on this aircraft



### OAT on Windshield

<b>A</b> Distance from top Windshield			
<b>B</b> Offset from Centerline			
OAT Offset (check one)	Left	Center	Right
<b>C</b> OAT Height			

### OAT on Side Window

<b>A</b> Distance back from fwd edge	
<b>B</b> Distance up from lower edge	
<b>C</b> OAT Height	

rev. date: 2/15/07










Additional Ordering Information: see Page 2


NAME: \_\_\_\_\_

# ANTENNA PLACEMENT WORKSHEET

INSTRUCTIONS: Print Form, Fill Out, Fax to 408/738-2729

## ANTENNA TYPES

1  Com Antenna type 1	2  Com Antenna type 2	3  Com Antenna type 3	4  Large "V" Antenna	5  Mooney "7" Antenna
6  Small "V" Antenna	7  Garmin Fin / TCAS	8  ADF Wire Antenna: A	9  ADF Wire Antenna: B	<b>NOTE</b> If none of these, sketch outline of antenna, then measure length & width of base.



No antennae on this aircraft

**A** Distance from top of Windshield    **B** Length/Width of Antenna base    **C** Offset from Centerline    Antenna Offset (circle one)    **D** Slope length of Antenna (types 1-3)    **E** Antenna Type (see types above)

Example	<i>34 5/8"</i> <small>(inches or metric)</small>	<i>5 1/2" x 3 1/4"</i>	<i>9 1/2"</i>	Left <i>X</i> <small>(pilot)</small>	Center	Right <small>(co-pilot)</small>	<i>18"</i>	<i>1</i>
Antenna #1				Left	Center	Right		
Antenna #2				Left	Center	Right		
Antenna #3				Left	Center	Right		
Antenna #4				Left	Center	Right		

rev. date: 2/15/07

# Measuring for a Propellor Cover

INSTRUCTIONS: Print Form, Fill Out, Fax to 408/738-2729

Spinner and blade dimensions on propellers vary, even among similar models. Producing a well-made propellor cover depends upon the following measurements.


If you have any questions or problems, please call.

## Please Check One:



2-Blade

3-Blade

4-Blade



- A \_\_\_\_\_ (measure along surface of cone)
- B \_\_\_\_\_ (measure "straight line" base to tip)
- C \_\_\_\_\_ (base to top of blade root opening)
- D \_\_\_\_\_ (provide diameter or circumference)
- E \_\_\_\_\_ (provide diameter or circumference)
- F \_\_\_\_\_ (blade root to prop tip)
- G \_\_\_\_\_ (trailing edge to leading edge)
- H \_\_\_\_\_ (trailing edge to leading edge)
- J \_\_\_\_\_ (trailing edge to leading edge)







# VENTURI TUBE PLACEMENT WORKSHEET

INSTRUCTIONS: Print Form, Fill Out, Fax to 408/738-2729

## LEFT SIDE VIEW



## RIGHT SIDE VIEW



rev. date: 2/15/07